
IMPORTANT!! PLEASE READ ENTIRE INSTRUCTION SHEET BEFORE ASSEMBLY!!

IMPORTANT NOTE: Your sling seat may appear to be slightly warped. This is not unusual. Proper assembly procedure will straighten out the sling seat in the frame. There are four bolts used to attach the seat frame to the seat base. After inserting all the bolts, each of these bolts must be tightened a few revolutions at time in rotation.

Step 1: Identify all parts packed in the carton against the parts list. Remove all protective materials. Set parts on a flat, non-abrasive surface to avoid scratching. If you are missing any parts or are unsure how to proceed with assembly, call our Customer Service Center immediately at 1-800-416-3511. **Do not attempt to assemble chair if any parts are missing or damaged.**

IMPORTANT NOTE: Assembling this chair requires attaching the sling seat frame to the seat base. We recommend two people work together to assemble the chair since it is critical that all the holes in the seat frame are aligned exactly with the holes in the seat base. All bolts need to be inserted and tightened into the fixed nuts in a straight and direct path. Inserting the bolts at even the slightest angle could strip the nuts and bolts, damaging the entire chair.

- **Step 2**: Working from behind the chair, have another person stand in front of the chair and position the sling seat frame in between the arms of the seat base (as shown) so that the holes on both sides of the upper portion of the seat frame back align with the fixed nut holes in the seat base.
- **Step 3**: From behind the chair, insert a bolt (1/4"x35mm) through the hole on one side of upper portion of the seat frame and into the fixed nut in the back arm portion of the seat base. Make sure the bolt is inserted exactly straight! Hand tighten 3-4 revolution only. **DO NOT TIGHTEN COMPLETELY.** Repeat for opposite side of chair.
- **Step 4**: Working from the front of the chair, add a washer to a bolt (1/4"x45mm). From the underside of the front seat support bar, insert bolt with washer through one of the holes in the seat support bar, into the fixed nut inside the lower front portion of the seat frame. Hand tighten 3-4 revolutions only. **DO NOT TIGHTEN COMPLETELY.** Repeat for opposite side.
- Step 5: Tighten all bolts. Each bolt must be tightened a 3-4 revolutions only at a time. Begin with top left bolt. Move to bottom right bolt then to top right bolt, followed by bottom left bolt. Repeat this "X" pattern until all bolts are tight. DO NOT OVER TIGHTEN BOLTS. Over tightening may strip bolts or nuts, damaging the entire chair.
- **Step 6**: Examine the chair from the front. If the sling seat does not appear tight or straight in the seat base, repeat steps 3, 4 and 5. If you do not feel your chair is assembled properly, or you have any questions, call our Customer Service Center at 1-800-416-3511.



		<u>\</u>	
	PARTS LIST	DESCRIPTION	QTY. / PCS
1		SEAT FRAME	1
2	M	SEAT BASE	1
3		1/4"x35MM BOLT	2
4		1/4"x45MM BOLT	2
5	0	WASHER	2
6		HEX BOLT DRIVER	1
7		HEX WRENCH	1

MODEL # 50-46490-487